

## Installatie instructie

### MyriaMesh BLC Remote switch three button



#### MyriaMesh Building Light Control Remote switch three button

De MyriaMesh Remote Switch three button is een onderdeel van de MyriaMesh Building Light Control product suite voor draadloze lichtbesturing. De Remote Switch is een batterij gevoede draadloze aan/uit/dim/scene knop die overal geplaatst kan worden. De Remote Switch biedt de mogelijkheid om van verlichting met de MyriaMesh lichtbesturing het licht aan/uit te schakelen, te dimmen of een scene te selecteren.



#### Veiligheid

- De installatie moet worden uitgevoerd door een installateur.
- Gebruik dit product niet als deze is beschadigd.
- De Remote switch bevat een **niet verwisselbare** en **niet oplaadbare** Lithium batterij.
- De Remote switch is bedoeld voor binnen gebruik of overdekt buiten gebruik (protectie klasse IP54).

#### Toepassing

- Lees de Remote switch productsheet (zie [chess-wise.eu/downloads](http://chess-wise.eu/downloads)) voor de product specificaties en gebruiksomstandigheden.

#### Installatie


- Monteer de bevestigingsplaat aan een wand of plafond met tenminste 2 schroeven of dubbelzijdig tape. Vermijd locaties met kans op stoten (b.v. door deuren of transport karren).
- Steek de Remote switch aan één zijde in de bevestigingsplaat en druk aan totdat deze vastklikt.

Contact informatie:  
[www.chess-wise.eu](http://www.chess-wise.eu)  
[info@chess-wise.eu](mailto:info@chess-wise.eu)  
Tel: +31 (0)23 51 49 149

Bezoek adres:  
Chess Wise BV  
Richard Holkade 8A  
2033 PZ Haarlem  
Nederland

V6-20171221

## Installatie instructie MyriaMesh BLC Remote switch three button



### Configuratie

Gebruik de iPad MyriaMesh commission app voor configuratie van de Remote switch. Zet de remote switch in *commission mode* door zowel de linker en rechter knop in te drukken totdat 3 piepjes zijn gegeven. Na een druk op één van de knoppen of 60 sec zal de Remote switch teruggaan naar *normal mode*.

| Linker en rechter knop ingedrukt | Toon | Functie  |
|----------------------------------|------|--|
| 3 sec                            | 3x   | Commission mode (na 60 sec terug naar normal mode) |
| één knop kort                    | 2x   | Normal mode  |

### Gebruik

Voor operationeel gebruik van de Remote switch in het MyriaMesh netwerk moet deze in *normal mode* staan.

### Conformiteit

Dit produkt voldoet aan de Europese richtlijnen en relevante standaarden voor laagspanning, EMC, RED, REACH, en RoHS. De Remote switch is voorzien van een radio. De gebruikte radiofrequentie ligt in de ISM frequentieband van 2400 – 2483.5 MHz (standaard 2403 MHz) en het maximum zendvermogen is +4 dBm. Hierbij, verklaart Chess Wise dat de radio van het type Remote switch three button voldoet aan richtlijn 2014/53/EU. De volledige tekst van de EU conformiteitsverklaring is beschikbaar op [chess-wise.eu/downloads](http://chess-wise.eu/downloads).

### Reparatie

Open dit produkt niet. In het geval van een defect moet de Multi sensor worden vervangen.



### Hergebruik

Gooi dit produkt niet weg bij het huisvuil, maar breng het naar een inzamelpunt voor hergebruik.

Contact informatie:  
[www.chess-wise.eu](http://www.chess-wise.eu)  
[info@chess-wise.eu](mailto:info@chess-wise.eu)  
 Tel: +31 (0)23 51 49 149

V6-20171221

Bezoek adres:  
 Chess Wise BV  
 Richard Holkade 8A  
 2033 PZ Haarlem  
 Nederland

## Installation instruction

### MyriaMesh BLC Remote switch three button



#### MyriaMesh Building Light Control Remote switch three button

The MyriaMesh Remote Switch three button is part of the MyriaMesh Building Light Control product suite for wireless lighting control. The Remote Switch is a wireless light/dimming/scene switch with a lifetime battery for flexible wall mounting. The Remote Switch enables you to switch on/off the light, step less dim the light or select a scene for lighting fixtures equipped with MyriaMesh light control.



#### Safety

- Installation should be performed only by qualified personnel.
- Do not use the Remote switch if it is damaged.
- This product contains a **non-replaceable** and **non-rechargeable** Lithium battery.
- The BLC200 has protection class IP54 and is suitable for use at indoor and covered outdoor locations.

#### Application

- Refer to the Remote switch product sheet (see [chess-wise.eu/downloads](http://chess-wise.eu/downloads)) for the product specifications and the environmental conditions.

#### Installation


- Attach the mounting plate with at least 2 screws or double-sided adhesive tape to a wall or ceiling. Avoid positions vulnerable for mechanical impact (e.g. by transport carts).
- Insert the Remote switch at one side in the mounting plate and push the switch until it locks.

Contact information:  
[www.chess-wise.eu](http://www.chess-wise.eu)  
[info@chess-wise.eu](mailto:info@chess-wise.eu)  
Tel: +31 (0)23 51 49 149

V6-20171221

Visiting address:  
Chess Wise BV  
Richard Holkade 8A  
2033 PZ Haarlem  
The Netherlands

## Installation instruction MyriaMesh BLC Remote switch three button



### Configuration

Use the iPad MyriaMesh commission app for configuration of the Remote switch. First enable *commission mode* by operating both the left and right switch until 3 beeps are given. After pushing of one of the buttons or 30 sec the Remote switch will go to *normal mode* again.

| Operate left and right button for | Beep | Function   |
|-----------------------------------|------|--|
| 3 sec                             | 2x   | Normal mode  |
| 6 sec                             | 3x   | Commission mode (after 30 sec back to normal mode) |

### Usage

For operational use in the MyriaMesh network the Remote switch must be in *normal mode*.

### Compliance

This product complies with the European directives and relevant standards for low voltage, EMC, RED, REACH and RoHS. The Remote switch three button contains a radio. The applied radio frequency is within the ISM band 2400 – 2483.5 MHz (default 2403 MHz) and the maximum transmit power is +4 dBm. Hereby, Chess Wise declares that the radio equipment type Remote switch three button is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at [chess-wise.eu/downloads](http://chess-wise.eu/downloads).

### Repair

Do not open this product. In case of failure the Multi sensor must be replaced.



### Recycling

Do not dispose this product as household waste, but bring it to an appropriate collection point for recycling.

Contact information:  
[www.chess-wise.eu](http://www.chess-wise.eu)  
[info@chess-wise.eu](mailto:info@chess-wise.eu)  
 Tel: +31 (0)23 51 49 149

V6-20171221

Visiting address:  
 Chess Wise BV  
 Richard Holkade 8A  
 2033 PZ Haarlem  
 The Netherlands